

Screw length

- In the majority of situations, 13mm screws will be appropriate. For very thin sternums, 10mm screws are also available
- The screwdriver has a built-in measuring device. Place the large shoulder of the screwdriver on the top of the sternum and note the location of the next ridge machined into the bit. This indicates the position where the tip of a 13mm screw would extend.
- Note: 10 and 13mm are the overall lengths of the screws, not the amount that extends into the bone.

